COOKTOP PARTS

For Models: WERP3120PQ3, WERP3120PB3
(White) (Black)

30" ELECTRIC FREESTANDING
SELF CLEAN RANGE



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10017610	Owners Manual
	9758505	Tech Sheet
	9756848	Installation Instructions Template, Anti−Tip
	9757143	English/French
	9757142	English/Spanish
2		Bowl, Drip
	3196202	6" Black
	3196203	8" Black
3		Cooktop
	3186231	White
	3186233	Black
4	3195060	Hinge, Cooktop (2)
5	3196178	Screw
6	308605	Strain Relief
7	3195812	Rod, Support (2)
9	814399	Receptacle, Elmnt
10	3196154	Screw
11		Element, Surface
	9761347	6" (2)
	9761345	8" (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRAWER & BROILER PARTS

For Models: WERP3120PQ3, WERP3120PB3
(White) (Black)



Illus. No.	Part No.	DESCRIPTION
1	3195710	Rack, Oven (2)
2	3195996	Grill, Broiler
3	3196076	Pan, Broiler
4	9761030	Drawer, Storage
5	9758200	Bracket, Drawer(2)
6		Rivet, Push (2)
	3196814	White
	3196813	Black
7		Panel, Drawer Frnt
	8053339	White
	8053341	Black
8	8053334	Glide, Drawer (2)
9	3196168	Screw
10	9756711	Heat Shield, Drawer
11	8274021	Rack, Partial
12	8274022	Rack, Insert

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: WERP3120PQ3, WERP3120PB3
(White) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: WERP3120PQ3, WERP3120PB3
(White) (Black)

Illus. No.	Part No.	DESCRIPTION
1	9755804	Vent Tube
2	3186144	Box, Burner
3		Panel, Side (2)
	8053830	White−Textured
	8053832	Black−Textured
4	W10010350	Seal, Oven Flange
5	8522416	Seal, Oven Door
6	9757341	Element, Broil
7	9755770	Element, Bake (Hidden)
8	9757239	Rod − Dr Switch
9	3196548	Fuse, Thermal
10	9759785	Glide, Drawer Frnt
11	3196037	Foot, Front (2)
12		Frame, Front Not Serviced
13	8054068	Tray, Insulation
14	3196576	Clip, Panel (6)
15	9760314	Rail, Base (2)
16	9761935	Foot, Rear (2)
17	9780585	Guard, Wire
18	3195809	Bumper, Side (2)
19	3186116	Support, Oven (2)
20	3186034	Bracket, Service
21	4449868	Block, Terminal
	112432	Nut (3)
22	8274034	Back, Main
23	9757262	Switch, Door
24	3196701	Light Socket Assy
25	311255	Bulb, Oven Light
26	9755771	Cover, Tray
27	8273902	Sensor, Oven
28	3196165	Screw
29	3196179	Screw
30	3196178	Screw
31	3400016	Screw
32	9760407	Brkt, Mounting
33	3196172	Screw
34	W10031780	Screw
35	3196567	Screw
36	3196168	Screw
37	3196174	Screw
38	9758238	Retainer, Side (2)
39	9761490	Insulation
40	3195813	Clip − Mounting
41	9761013	Latch, Door
42	3196961	Rod, Latch
43	9757241	Latch Asy, Rear
44	9758701	Spacer, Door
45	3196169	Screw
46	9755769	Tray, Hidden Bake Element
47	9759689	Card, Insulator
48	3196560	Screw (2)
49	9758283	Cover, Box

INSULATION

	8272616	Insulation, Wrap
	9755772	Insulation, Back

CONTROL PANEL PARTS

For Models: WERP3120PQ3, WERP3120PB3
(White) (Black)



CONTROL PANEL PARTS

For Models: WERP3120PQ3, WERP3120PB3
(White) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Endcap
	W10009040	White Left Hand
	W10009050	White Right Hand
	W10009080	Black Left Hand
	W10009090	Black Right Hand
2	9756364	Bracket, Console
3		Panel, Control
	9763289	White
	9763290	Black
4		Switch, Infinite
	3148954	Left Front
	3148952	Left Rear
	3148954	Right Rear
	3148952	Right Front
5	8523265	Light, Indicator
6	3196068	Lens, Light
7		Knob, Infinite (4)
	9757132	White
	9758129	Black
8	8053912	Shield, Heat
9		Bracket, Control
	9758480	White
	9758481	Black
10	9756999	Cover, Rear
12	9757271	Control, Range
13	3196178	Screw
14	9757609	Nameplate
15	9756366	Cover, Rear (Console)
16	3400882	Screw
17	3196200	Clip, Spring (2)
19		Breaker, 15Amp
	9757601	White
	9757602	Black
20		Receptacle
	9758889	White
	9758890	Black
21	9757358	Reflector, Light
22		Screw
	3196166	White
	8281194	Black
23	9757490	Support, Glass
24	3196178	Screw

DOOR PARTS

For Models: WERP3120PQ2, WERP3120PB2

(White) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: WERP3120PQ3, WERP3120PB3
(White) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Trim, Top
	W10016370	White
	W10016380	Black
2	3196164	Screw
3		Handle, Door
	8522444	White
	3195922	Black
4	9761344	Liner, Door
5	8522414	Seal, Window
6	9758162	Glass, Inner (2)
7	3186289	Frame, Glass
8	8272618	Insulation, Door
9	9761357	Retainer, Insul.
10	9761493	Hinge, Door (2)
11		Glass, Outer
	9756415	White
	9756414	Black
12		Trim, Side
	8523166	White Left Hand
	8523172	White Right Hand
	8523171	Black Left Hand
	8523165	Black Right Hand
13	3196160	Screw
14		Trim, Lower
	8523175	White
	8523177	Black
15	3196025	Clip, Glass (4)
17	W10031780	Screw
18	W10031790	Screw
19	9761517	Clip, Dr Mntg (2)
20	3196165	Screw
21	3195809	Bumper, Door (2)
22	3196794	Bracket, Window(2)

OPTIONAL PARTS (NOT INCLUDED)

For Models: WERP3120PQ3, WERP3120PB3
(White) (Black)

Illus. No.	Part No.	DESCRIPTION

Following Parts Not Illustrated

SPLICING WIRES−−25FT. LENGTH

242828	Wire, Black 12 Ga. 150° c
242821	Wire, Blue 14 Ga. 150°c
242822	Wire, Brown 14 Ga. 150°c
242830	Wire, Brown 14 Ga. 200°c
242823	Wire, Green 14 Ga. 150°c
242824	Wire, Orange 14 Ga. 150°c
242825	Wire, Red 14 Ga. 150°c
242831	Wire, Red 14 Ga. 200°c
242827	Wire, Yellow 14 Ga. 150°c

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch−Up Self−Clean(1/2 Pt)
261582	Grease

INSULATION

261514	Insulation, Fiberglass (1−1/2" x 24" x 120")
240132	Insulation, Fiberglass (2−1/2" x 22" x 120")

PAINT, TOUCH−UP (1/2oz.)

72017	White
4392899	Biscuit
511873	White Porcelain (2 Oz.)

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
4392901	Biscuit
285006	Superior Black
206922	Primer (White)

PAINT, BULK (1 qt.)

799344	White (Uncut)
4392900	Biscuit (Uncut)

ACCESSORY PARTS

241430	Foil, Aluminum Oven (18" x 25')
3184478	Cleaner, Glass

ANTI−TIP KIT

W10017440	Anti−Tip Kit

WIRING HARNESS PARTS

9761475	Harness, Wire (Surface Unit)
9759588	Harness, Wire (Main)
9758174	Harness,Wire (Sensor/Dr Switch)
9756350	Power Cord
9756779	Strain Relief
3196173	Screw
9757339	Harness, Bake Element (Hidden)
311227	Wire, Ground
3196154	Screw
9762425	Harness, Wire (Flex Cnnct Cable)
3196520	Clip, Wire Ground